


CODIGO **41261**

DESCRIPCION: **MANIOBRA ELECTRONICA DUCHA WELLMA**




ESPAÑOL

POS	CODIGO	DESCRIPCION	CANTIDAD	POS	CODIGO	DESCRIPCION	CANTIDAD
1	4410010004	DISPLAY TACTIL		3	4410010005	ARMARIO DE MANIOBRA	
2	4410010001	JUNTA ESTANQUEIDAD					

CODE **41261**

DESCRIPTION: **MANŒUVRE ÉLECTRONIQUE DOUCHE WELLMA**




FRANCAIS

POS	CODE	DESCRIPTION	QUANTITE	POS	CODE	DESCRIPTION	QUANTITE
1	4410010004	ÉCRAN TACTILE		3	4410010005	COFFRET COMMANDE	
2	4410010001	JOINT					

CODE **41261**

DESCRIPTION: **ELECTRONIC MANEUVER WELLMA SHOWER**




ENGLISH

POS	CODE	DESCRIPTION	QUANTITY	POS	CODE	DESCRIPTION	QUANTITY
1	4410010004	TOUCH DISPLAY		3	4410010005	CONTROL PANEL	
2	4410010001	GASKET					

CODICE **41261**

DESCRIZIONE: **MANOVRA ELETTRONICA DOCCIA WELLMA**




ITALIANO

POS	CODICE	DESCRIZIONE	QUANTITA'	POS	CODICE	DESCRIZIONE	QUANTITA'
1	4410010004	DISPLAY TOUCH		3	4410010005	QUADRO ELETTRICO	
2	4410010001	GUARNIZIONE					

CODE **41261**

BESCHREIBUNG: **ELEKTRONISCHE STEUERUNG DUSCHE WELLMA**




DEUTSCH

POS	CODE	BESCHREIBUNG	MENGE	POS	CODE	BESCHREIBUNG	MENGE
1	4410010004	TOUCHSCREEN		3	4410010005	STEUERSCHRANK	
2	4410010001	DICHTUNG					

CODIGO **41261**

DESCRIÇÃO: **COMANDO ELETRÓNICO DUCHE WELLMA**



PORTUGUES

POS	CODIGO	DESCRIÇÃO	JANTIDADE	POS	CODIGO	DESCRIÇÃO	JANTIDADE
1	4410010004	DISPLAY TACTIL		3	4410010005	QUADRO DE MANOBRA	
2	4410010001	JUNTA					